


SECTION 9: PARTS

Parts Breakdown




Parts List

REF	PART #	DESCRIPTION
1	P0692001	BASE
2	P0692002	ANCHOR HOUSING
3	PSB40M	CAP SCREW M8-1.25 X 35
4	PLW04M	LOCK WASHER 8MM
5	P0692005	WISE SLIDE PLATE
6	P0692006	MOTOR TILT BASE
7	P6202LLB	BALL BEARING 6202LLB
8	P0692008	ROTOR
9	P6000LLB	BALL BEARING 6000LLB
10	P0692010	AIR FLOW COVER
11	P0692011	MOTOR FRAME
12	P0692012	BRUSH HOLDER
13	PW05M	FLAT WASHER 4MM
14	PHTEK31M	TAP SCREW M4 X 14
15	P0692015	STATOR
16	PTLW02M	EXT TOOTH WASHER 5MM
17	PHTEK43M	TAP SCREW M5 X 70
18	PW02M	FLAT WASHER 5MM
19	PLW01M	LOCK WASHER 5MM
20	P0692020	CAP SCREW M5-.8 X 28
21	P0692021	CARBON BRUSH SET
22	P0692022	COVER
23	PW05M	FLAT WASHER 4MM
24	PHTEK6M	TAP SCREW M4 X 16
25	P0692025	GEAR SHAFT
26	PK19M	KEY 5 X 5 X 14
27	P0692027	PINION M1.25 X 43T
28	PEC03M	E-CLIP 10MM
29	P6000LLB	BALL BEARING 6000LLB
30	P0692030	ARBOR
31	P6205LLB	BALL BEARING 6205LLB
32	P0692032	GEAR M1.5 X 40T
33	PK14M	KEY 5 X 5 X 18
34	PEC03M	E-CLIP 25MM
35	P6200LLB	BALL BEARING 6200LLB
36	P0692036	GEAR BOX
37	P0692037	LOWER SWITCH HANDLE
38	PW05M	FLAT WASHER 4MM
39	PHTEK28M	TAP SCREW M4 X 25
40	P0692040	TRIGGER SWITCH
41	PW05M	FLAT WASHER 4MM
42	PHTEK39M	TAP SCREW M4 X 12
43	P0692043	WIRE RETAINER
44	P0692044	UPPER SWITCH HANDLE
45	PHTEK42M	TAP SCREW M4 X 35
46	P0692046	WIRE GUARD
47	P0692047	POWER CORD 110V 8'
48	P0692048	RIGHT SIDE HANDLE
49	P0692049	LEFT SIDE HANDLE
50	P6000LLB	BALL BEARING 6000LLB
51	P0692051	GUARD TUBE
52	P0692052	FRONT SHAFT BRAKE LEVER
53	P0692053	COMPRESSION SPRING
54	P0692054	SAWBLADE GUARD
55	PSB137M	CAP SCREW M5-.8 X 55

REF	PART #	DESCRIPTION
56	P0692056	BEARING BUSHING
57	P6000LLB	BALL BEARING 6000LLB
58	PW03M	FLAT WASHER 6MM
59	PLW03M	LOCK WASHER 6MM
60	PSB02M	CAP SCREW M6-1 X 20
61	P0692061	RUBBER SEAT
62	PSB26M	CAP SCREW M6-1 X 12
63	P0692063	CENTER COVER
64	P6000LLB	BALL BEARING 6000LLB
65	PSB33M	CAP SCREW M5-.8 X 12
66	P0692066	SLIDING GUARD ASSEMBLY
67	P0692067	CONNECTION ROD ASSEMBLY
68	P0692068	SPECIAL CAP SCREW M5-.8 X 12
69	P0692069	GUARD BUSHING
70	PW01M	FLAT WASHER 8MM
71	P0692071	CONNECTION ROD BUSHING
72	PB84M	HEX BOLT M8-1.25 X 14
73	P0692073	LOCK LEVER
74	P0692074	RUBBER RING
75	P0692075	KNOB HANDLE
76	PR04M	EXT RETAINING RING 6MM
77	P0692077	SHAFT
78	PSB04M	CAP SCREW M6-1 X 10
79	P0692079	SPRING SEAT SHAFT
80	P0692080	SPRING RUBBER SEAT
81	P0692081	COMPRESSION SPRING
82	PN03M	HEX NUT M8-1.25
83	PB126M	HEX BOLT M8-1.25 X 40
84	P0692084	ARBOR FLANGE
85	T20920	BLADE 58-T 350 X 2.4 X 25.4MM
86	P0692086	CLAMP WASHER
87	PB56M	CAP SCREW M10-1.5 X 20
88	P0692088	PIVOT SHAFT
89	P0692089	FIXED VISE JAW
90	P0692090	ANGLE SCALE
91	P0692091	DISC SPRING
92	P0692092	BUSHING
93	P0692093	PULL BAR
94	PSB26M	CAP SCREW M6-1 X 12
95	P0692095	T-NUT M8-1.25
96	P0692096	SPACER RING
97	P0692097	STUD
98	P0692098	LEVER
99	PFH02M	FLAT HD SCR M6-1 X 12
100	P0692100	SADDLE
101	P0692101	COMPRESSION SPRING
102	P0692102	STEEL BALL
103	P0692103	LEADSCREW ASSEMBLY
104	PN02M	HEX NUT M10-1.5
105	PW04M	FLAT WASHER 10MM
106	P0692106	SLAG TRAY SLIDE
107	PSB23M	CAP SCREW M4-.7 X 12
108	PLW02M	LOCK WASHER 4MM
109	P0692109	SLAG TRAY
110	PW02M	FLAT WASHER 5MM



Warning Labels



REF	PART #	DESCRIPTION
200	PLABEL-14B	ELECTRICITY LABEL
201	P0692201	READ MANUAL LABEL
202	P0692202	WEAR SAFETY GLASSES LABEL
203	P0692203	AMPUTATION WARNING LABEL

REF	PART #	DESCRIPTION
204	P0692204	HEARING WARNING LABEL
205	P0692205	DISCONNECT POWER LABEL
206	P0692206	MACHINE ID LABEL

! WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

